



## How-To-Use

# SikaGrout® 212

## Anchoring Grout

### Materials:

- Safety glasses and gloves
- Bag of SikaGrout 212
- Sufficient water for desired mix
- Mixing container
- Mixing paddle
- Trowel or shovel (for smaller quantities)
- Drill and mortar paddle (for larger quantities)

### Procedure

1. Remember to always wear waterproof gloves and safety goggles whenever mixing or using cement-based products.
2. Mix the grout with clean water in a separate mixing container for 3 minutes to obtain desired consistency. Add only enough water to achieve the flow required for the application. Less water for dry-pack consistency and more water for a fluid consistency. Maximum addition of water is 8.5 pints per 50 lb. bag.
3. Small quantities can be mixed with a trowel or shovel. For best results, larger quantities should be mixed with a slow speed drill and mortar paddle or a conventional mortar mixer.
4. Within 15 minutes of mixing, place the grout in the hole or void. Pour or ram grout as necessary, to fill the form area.



## Guía de Uso

# SikaGrout® 212

## Anchoring Grout

### Materials:

- Gafas de seguridad y guantes impermeables
- Bolsa de SikaGrout 212
- Suficiente agua para la mezcla deseada
- Recipiente de mezcla
- Llana o pala (para cantidades pequeñas)
- Taladro y paleta de mezcla or mezclador portátil para morteros (para cantidades grandes)

### Procedure

1. Recuerde de siempre usar guantes impermeables y gafas de seguridad al mezclar y usar productos con base en cemento.
2. Mezcle el mortero con agua potable en un recipiente por 3 minutos hasta obtener la consistencia deseada. Añada únicamente el agua necesario para alcanzar la fluidez deseada para la aplicación (menos agua para una consistencia pastosa y más agua para una consistencia fluida). La máxima cantidad de agua es de 136 onzas fluidas por bolsa de 50 libras.
3. Cantidades pequeñas se pueden mezclar con llana o pala. Para mejores resultados, cantidades grandes se deben mezclar con taladro y paleta de mezcla o en un mezclador portátil para morteros.
4. El producto se debe colocar dentro de los 15 minutos después de mezclado. Según el caso, vierta or presione el producto dentro del espacio u hoyo para rellenar completamente el área preparada.