



How-To-Use Sikacryl® Concrete Patch Ready-Mix Repair

Materials:

- Safety glasses and gloves
- 1 quart tub of Sikacryl Concrete Patch
- Margin trowel or putty knife
- Wire brush
- Water & clean rag for clean up

Procedure

1. Make sure that all surfaces are clean, sound, dry and free from dirt and loose particles.
2. For best results, use a wire brush to clean off any loose particles or excess dirt or dust.
3. With the trowel or putty knife, stir material thoroughly until a uniform appearance is achieved prior to use.
4. Ensure that enough product is pushed into crack or hole to provide coverage. Tool as needed.
5. Areas greater than 1/4 inch deep may require two or more applications.
6. Allow repaired area to fully cure for at least 24 hours minimum.
7. Clean up all tools, spills, and excess material immediately with water and clean rag after use.