

NOTES:

- NEW OR EXISTING WOOD NAILERS SHALL BE ATTACHED ACCORDING TO THE D.O.R., LOCAL CODE, OR INSURANCE REQUIREMENTS, WHICHEVER IS MORE STRINGENT. NAILER HEIGHT TO MATCH TOP SURFACE TO WHICH MEMBRANE IS TO BE APPLIED.
- 2) SARNAFIL S 327 COVER STRIP IS TO BE HOT AIR WELDED TO SARNAFIL MEMBRANE AND THEN SET INTO SIKAFAST 3341 ADHESIVE.
- 3) PAINTERS TAPE IS TO BE CENTERED OVER THE OUTSIDE EDGE OF COVER STRIP AS SIKAFAST 3341 ADHESIVE CURES (TEMPORARY).

METAL FLASHING WITH SIKAFAST 3341

