



NOTES:

1. OPEN CRACK OR JOINT BY CHIPPING OR SAWCUTTING
2. PRIME CONCRETE
3. FILL CRACK OR JOINT WITH BASE COAT MIX OF SIKAFLOOR-61 BC PRONTO WITH SIKAFLOOR-100 SL PRONTO
4. INSTALL SIKAFLOOR® PRONTO MMA FLOORING SYSTEM

CURRENT ISSUE DATE: June 10, 2024	DRAWN BY: HAJ
DATE CREATED: June 10, 2024	CHECKED BY: WJG
DRAWING NO: CB-27.1	

STANDARD DETAIL
SIKAFLOOR® PRONTO MMA
 Control Joint or Crack Repair

BUILDING TRUST



Sika Corporation
 201 Polito Ave
 Lyndhurst, NJ 07071
 usa.sika.com

Information provided herein, including but not limited to, any drawing, design, photograph, graphic, or statement(s) ("Materials") are proprietary and the property of Master Builders Solutions Construction Systems US, LLC ("Company"). Reproduction, translation, or reduction to any electronic medium or machine readable form, in whole or part, is strictly prohibited, except for the express purpose for which it has been furnished, without prior written consent of Company. All Materials contained herein are provided by Company for information purposes only. Company reserves the right to amend or withdraw any information contained in the Materials without notice. All technical or other advice by Company, whether verbal or written, concerning products, or the use of products in specific situations ("Advice") is given by Company and is used at the Users own risk.