



## How-To-Use

# Sikagard® Natural Look Sealer Water Repellent Sealer

### Materials:

- Safety glasses and waterproof gloves
- Gallon of Sikagard Natural Look Sealer
- Desired application tool - sprayer, brush or roller

### Procedure

1. **Note:** A preliminary site test application is recommended (preferably on a small, prepped, inconspicuous surface) to determine satisfactory appearance and surface slip resistance.
2. Remember to always wear waterproof gloves and safety goggles. Surface must be clean, sound, dust-free and dry. Remove all dust, dirt, loose concrete, grease, curing compounds, paint and other particles by mechanical means (i.e. pressure wash, blast clean, etc).
3. Shake product thoroughly before applying.
4. Sikagard Natural Look Sealer can be applied by sprayer, brush or roller. Apply over entire area moving in one direction. A maximum of two coats may be necessary, depending on the porosity of the substrate.

### Special Tips

- Substrate must be dry prior to application (minimum 48 hrs.)
- Recommended application temperature is 45°- 95°F (5°-35°C).
- Do not apply if rain is in the forecast
- Cannot seal visible cracks; Repair all surface cracks or defects before applying sealer
- Do not use on concrete under 7 days old
- Avoid puddling; apply even coats
- Do not attempt to build up thickness



## Guía de Uso

# Sikagard® Natural Look Sealer

## Sellador Impermeable

### Materiales:

- Gafas y de seguridad y guantes impermeables
- El galón de Sikagard Natural Look Sealer
- Herramientas rodillo, aspersor o brocha

### Procedimiento

1. **Nota:** Se recomienda una aplicación preliminar de prueba en sitio (preferiblemente en una pequeña superficie preparada y poco visible) para determinar la apariencia satisfactoria y la resistencia al deslizamiento superficial.
2. Recuerde de siempre usar guantes impermeables y gafas de seguridad.
3. Agite el producto bien antes de aplicar.
4. El Sikagard Natural Look Sealer se puede aplicar con rodillo, brocha o aspersor. Aplique sobre toda el área moviéndose en una dirección. Un máximo de dos capas puede ser necesario, dependiendo de la porosidad de la superficie.

### Consejos

- El sustrato debe estar seco antes de la aplicación (mínimo 48 horas)
- La temperatura de aplicación recomendada es 45°- 95°F (5°- 35°C).
- No aplique si la lluvia está en el pronóstico
- No se pueden sellar grietas visibles. Repare todas las grietas o defectos en la superficie antes de aplicar el sellador
- No use en hormigón con menos de 7 días de curado
- Evite encharcamiento; Aplique capas uniformes
- No intente aumentar el grosor con el sellador