



How-To-Use Sika[®] Backer Rod

Materials:

- Safety glasses and gloves
- Bag of Sika Backer Rod
- Utility knife
- Wire brush
- Blunt tool or roller

Procedure

1. Wearing protective gloves and safety goggles, clean joints with wire brush, removing all dirt, grass, debris and old filler material.
2. Push backer rod into the joint and with knife, cut to desired length. If necessary, use a blunt tool or roller to secure backer rod in the joint. Joint width to depth should be 2 to 1 with a minimum depth of 1/4" or a maximum depth of 1/2". For best results, diameter of the backer rod should be 1/8" larger than the width of the joint.
3. For joints larger than backer rod, twist two strands of the rod together to fill the gap, then seal per the label recommendations.
4. If the backer rod should get punctured, wait a half hour before applying the sealant.



Guía de Uso

Sika® Backer Rod

Perfil de Espuma de Célula Cerrada par Relleno de Juntas

Materials:

- Gafas y guantes de seguridad
- Bolsa de Sika Backer Rod
- Cuchillo de uso general
- Cepillo de alambre
- Rodillo

Procedure

1. Utilizando guantes y gafas de seguridad, limpie la junta con un cepillo de alambre, asegure que todo el sucio, yerba, escombros y sellador viejo sean removidos.
2. Empuje el perfil dentro de la junta. Si es necesario, puede utilizar un rodillo. El factor forma del sellador (proporción ancho:profundidad) es 2 a 1 con una profundidad mínima de 1/4" y un máximo de media pulgada. El ancho apropiado del perfil debe ser 1/8" más ancho que el de la junta.
3. Para juntas más de 1" de ancho, puede juntar dos tiras del perfil para rellenar la junta a la profundidad especificada por las recomendaciones de uso del sellador.
4. Si se perfora el perfil mientras es colocado en sitio, se debe esperar media hora, antes de aplicar el sellador.