

APPLICATION MANUAL SikaProof® A+



The information contained herein and any other advice are given in good faith – based on Sika Waterproofing current knowledge and experience of products when properly stored, handled and applied under normal conditions in accordance with Sika Waterproofing recommendations. The information given only apply to the applications and products expressly referred to herein. The information given is based on laboratory tests which do not replace practical tests. In case of changes in any parameter of the application, such as changes in substrates, or in case of a different application, consult Sika Waterproofing Technical Service prior to using Sika Waterproofing products. The information contained herein does not relieve the user of the products from testing them for the intended application and purpose. All orders are accepted subject to our current terms of sale and delivery. Users must always refer to the most recent issue of the local Product Data Sheet for the product concerned. Copies of which will be supplied on request.	

CONTENT

SikaProof® A+

General Information

- 5 What is SikaProof® A+
- The Products
- Application Tools
- Sealing and Bonding of Membrane Joints
- Substrate Preparation
- Inspection

Installation

- 12 Installation of Membrane Sheets
- 13 SikaProof® Tape A+
- 14 SikaProof® Tape A+
- 15 SikaProof® Sandwich Tape 16 SikaProof® Sandwich Tape
- Installation of Perimeter Edges and Base Slah
- 18 Base Slab Application

Detailing

- 21 General Information
- 22 Inside Corners
- 27 Outside Corners
- 31 Pipe Penetration
- 33 Pile Head

Post Installation Work

- 36 General Information
- 37 Formwork Tie-Bars
- 38 Expansion and Construction Joints 39 SikaProof® A+ System Components &
- Accessories
- 40 Complementary Joint Sealing Products

Cleaning

41 General Information

Repair

44 General Information

Protection


46 General Information

1 SikaProof® A+

GENERAL INFORMATION

- 5 What is SikaProof® A-
- 6 The Products
- 7 Application Tools
- 8 Sealing and Bonding of Membrane Joints
- 9 Substrate Preparation
- 10 Inspection

GENERAL INFORMATION WHAT IS SikaProof® A+




Highly flexible FPO membrane

- High crack-bridging capability
- 1.75 mm total thickness

Unique hybrid technology

 Polymer modified cementitious bonding layer



Pre-applied fully bonded waterproofing system

- No lateral water migration
- Mechanical bond to structure due to coarse structure
- Adhesive bond to structure due to cement content and special polymer



Sealing and bonding

- Single tapes solution
- $\hfill \blacksquare$ Easy, fast and safe installation
- Simple application for detailing (pipe penetration, pile heads, etc.)

GENERAL INFORMATION

THE PRODUCTS

SAP No.	Product	Packaging	Size	Unit	Quantity/Unit	Packaging Units					
SYSTEM COMPONENTS											
571641	SikaProof® A+ 12	roll	2.00 x 20 m	m²	40 m²	Single roll					
571640	SikaProof® A+ 12	roll	1.00 x 20 m	m²	20 m²	Single roll					
571628	SikaProof® Tape A+	roll	0.15 x 25 m	m	25 m	2 Rolls / box					
577412	SikaProof® Sandwich Tape	roll	0.05 x 25 m	m	25 m	5 Rolls / box					
ACCESSORIES											

ALLESSURIES

457589	SikaProof® Patch-200 B	roll	0.20 x 20 m	m	20 m	2 Rolls / box
424701	SikaProof® FixTape-50	roll	0.05 x 20 m	m	20 m	5 Rolls / box

GENERAL INFORMATION **APPLICATION TOOLS**



- Metal straight edge for cutting
- Clean, dry cloth
- Marking pen
- Tape measure
- Small pressure roller
- Membrane cutter
- Staple gun

GENERAL INFORMATION SEALING AND BONDING OF MEMBRANE JOINTS



- All overlaps are sealed and bonded with either the SikaProof® Tape A+ or the SikaProof® Sandwich Tape
- The minimum overlap is 5 cm



The SikaProof® Tape A+ is used for:

- As inside tape for jointing of overlaps
- Detailing (e.g. pipe penetrations, pile heads, inside & outside corner)



The SikaProof $^{\circ}$ Sandwich Tape is used for:

 Jointing of overlaps, especially for wall application with double-sided formwork

GENERAL INFORMATION SUBSTRATE PREPARATION





- Sufficient stability
- Avoid movement

Suitable substrates:

- Concrete blinding with a smooth surface finish (geotextile > 300 g/m²)
- Formwork
- Rigid thermal insulation
- Plywood
- Compacted soil





Surface:

- Smooth, uniform and clean.
- Free from oil, grease, dust and any other loose particles
- Large gaps and voids must be filled before the installation
- Damp or slightly wet, but no ponding water
- Substrate temperature has to be min. +5°C / max. + 60°C

GENERAL INFORMATION INSPECTION

Before Installation

- Substrate quality
- Evenness of application area
- Protection layer

During Installation

- Execution of detailing
- Damage to the membrane
- Soiling on membrane

After Installation

- Damage to the membrane
- Soiling on membrane
- Excess material on membrane (e.g. release liner, cut-offs, etc.)

1 SikaProof® A+

INSTALLATION

- 12 Installation of Membrane Sheets
- 13 SikaProof® Tape A-
- 14 SikaProof® Tape A+
- 15 SikaProof® Sandwich Tape
- 16 SikaProof® Sandwich Tape
- 17 Installation of Perimeter Edges and Base Slat
- 18 Base Slab Application



- The installation of SikaProof® A+ has to be carefully performed
- The system can be applied with the SikaProof® Tape A+ for internal jointing and detailing
- It is mandatory to comply with the umbrella principle when working with double-sided formwork
- The umbrella principle means that the in wall applications the top membrane is always on the outside when jointing with the lower membrane
- Alternatively, SikaProof® Sandwich Tape is be used for internal jointing, especially for wall application, when working with double-sided formwork

SikaProof® Tape A+





SikaProof® Sandwich Tape









INSTALLATION OF PERIMETER EDGES AND BASE SLAB



- Use black dotted line as auxiliary line
- Alternatively, SikaProof® Sandwich Tape can be used for internal jointing in wall applications




- Smooth and clean substrate
- If necessary, use protection layer
- All overlaps have to be minimum 5.0 cm
- Use black doted line as auxiliary line



- All T-joints must have an additional patch of tape
- All overlaps have to be minimum 5.0 cm
- Use black doted line as auxiliary line



BASE SLAB APPLICATION



2 SikaProof® A+

DETAILING


- 21 General Information
- 22 Inside Corners
- 27 Outside Corners
- 31 Pipe Penetration
- 33 Pile Head

DETAILING GENERAL INFORMATION




- In waterproofing membrane systems, the details are the most important part of the application
 Generally, it is differentiated between
- the inside corner, outside corner, pipe penetration and pile heads

 The proficient execution of the details is the
- The proficient execution of the details is the key for a durable and reliable waterproofing system
- The SikaProof® A+ system offers a simple and safe solution for different types of details





DETAILING INSIDE CORNERS







DETAILING INSIDE CORNERS





DETAILING OUTSIDE CORNERS






DETAILING OUTSIDE CORNERS





DETAILING OUTSIDE CORNERS




DETAILING PIPE PENETRATION















DETAILING PILE HEAD










3 SikaProof® A+

POST INSTALLATION WORK

- 36 General Information
- 37 Formwork Tie-Bars
- 38 Expansion and Construction Joints
- 39 SikaProof® A+ System Components & Accessories
- 40 Complementary Joint Sealing Products

POST INSTALLATION WORK **GENERAL INFORMATION**



For projects with double-sided formwork, additional sealing work has to be conducted to ensure a complete waterproofing basement structure.

Following elements have to be sealed:

- Tie-bar holes
- Expansion and Construction Joints

POST INSTALLATION WORK FORMWORK TIE-BARS



SikaProof® Patch-200 B



SikaProof® FixTape-50




- Fill tie bar hole with Sika® X-Plug
- Round off the edges of the patch
- Apply the patch on to the tie-bar hole



■ Press the entire patch with a roller

POST INSTALL ATION WORK **EXPANSION AND CONSTRUCTION JOINTS**



- For joints with anticipated movement, the use of Sikadur® Combiflex® SG joint sealing system is recommended
- Prior to using Sikadur® Combiflex® SG system, the application area on the SikaProof® A+ has to be flame-treated



- Pre-treat the concrete surface of the edge mechanically
- Clean the membrane surface
- Briefly pre-treat the membrane surface crosswise with an open torch
- Apply the Sikadur® Combiflex® SG system, according to the current Method Statement

SikaProof® A+ SYSTEM COMPONENTS & ACCESSORIES



1. 571640 - SikaProof® A+ 12 (1 x 20 m) 2. 571641 - SikaProof® A+ 12 (2 x 20 m)




571628 - SikaProof® Tape A+



577412 - SikaProof® Sandwich Tape



424701 - SikaProof® FixTape-50



457589 - SikaProof® Patch-200 B

COMPLEMENTARY JOINT SEALING PRODUCTS



Sikadur® Combiflex® SG System



SikaSwell® or Sika® Hydrotite®



SikaFuko®



Sika® Greenstreak® Waterstop

4 SikaProof® A+

CLEANING

41 General Information

CLEANING

GENERAL INFORMATION

The SikaProof® A+ membrane has to be cleaned if it is soiled or contaminated with any other materials to ensure a full bond with fresh concrete on the entire area of the membrane.

Procedure

- Compressed air
- Controlled high-pressure water cleaner
 - Max. pressure ≤ 3000 psi
 - Flat nozzles no spirals!
 - Min distance between the membrane surface and the jet nozzle ≥ 300 mm (12 in)
 - Do not point the nozzle directly at overlap joints
 - Optimum angle for the jet ≤ 60°

Remove all:

- Liners, membrane cut-offs and other waste materials
- Clean the excess rement laitance with water immediately after concreting, when it is still in its fresh state




- Debris, dirt, dust, soil, sand, concrete/ cement residues
- Anything that could create a separation layer or cause delamination

5 SikaProof® A+

REPAIR

44 General Information


REPAIR GENERAL INFORMATION





Any membrane damage ≤ 10 mm

■ Seal & bond an additional SikaProof® Tape A+ on the damaged area



Any membrane damage ≥ 10 mm

- Cover damaged area with a membrane piece
- The membrane piece has to overlap 5 cm on all sides
- Seal & bond the membrane piece with SikaProof® Tape A+ on all sides

6 SikaProof® A+

PROTECTION

46 General Information

PROTECTION

GENERAL INFORMATION

- Every membrane protection layer is temporary
- For concreting in stages a protection layer is required to prevent soiling on the membrane
- For duration of over 90 days between membrane installation and concreting, the SikaProof® A+ system hast be protected by UV-resistant layer

Options for protection layers:

- Plastic film/foil (UV resistant)
- Geotextile (UV resistant)
- Other equivalent measures





NOTES

NOTES





The sale of all Sika products are subject to the following Limited Warranty:

YTNARRAW JAIRSTAM DETIMIJ

PROPERTY RICHTS HELD BY OTHERS.

current Product Data Sheet if used as directed within shelf life. User determines suitability of product for intended use and assumes all risks. Buyer's Sike werrants this product for one year from date of installation to be free from manufacturing defects and to meet the technical properties on the

NOT BE RESPONSIBLE FOR THE USE OF THIS PRODUCT IN A MANNER TO INFRINCE ON ANY PATENT OR ANY OTHER INTELLECTUAL PARTICULAR PURPOSE. SIKA SHALL NOT BE LIABLE UNDER ANY LEGAL THEORY FOR SPECIAL OR CONSEQUENTIAL DAMAGES. SIKA SHALL NO OTHER WARRANTIES EXPRESS OR IMPLIED SHALL APPLY INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A sole remedy shall be limited to the purchase price or replacement of product exclusive of labor or cost of labor.

Our most current Ceneral Sales Conditions shall apply. Please consult the most current Product Data Sheet prior to any use.

Lontact **NOITAROGROD AXIZ**

4U26.225.008 Phone

usa.sika.com ASU 551511551008 XAA St. Louis, MO 63122 3400 Tree Court Industrial Blvd.

BUILDING TRUST