

## NOTES:

- 1) NEW OR EXISTING WOOD NAILERS SHALL BE ATTACHED ACCORDING TO THE D.O.R., LOCAL CODE, OR INSURANCE REQUIREMENTS, WHICHEVER IS MORE STRINGENT. NAILER HEIGHT TO MATCH TOP SURFACE TO WHICH MEMBRANE IS TO BE APPLIED.
- 2) BRING BAREBACK MEMBRANE OVER ROOF EDGE AND DOWN OUTSIDE FACE OF WALL, COVERING WOOD NAILER(S) COMPLETELY. BRING FELTBACK MEMBRANE TO ROOF EDGE ONLY.
- 3) USE GALVANIZED ANNULAR RING NAILS PENETRATING 1-1/4" MIN. (AS TESTED IN THE ES-1 TEST REPORT) OR NO. 8 MIN. SCREWS PENETRATING 3/4". FASTENERS ARE STAGGERED 4" O.C. TOP FASTENER IS PLACED EITHER CENTERED INTO TOP WOOD NAILER OR 1" MIN. FROM TOP EDGE OF CLEAT. BOTTOM FASTENER IS PLACED 1" MIN. FROM BOTTOM OF CLEAT OR CENTERED INTO WOOD NAILER.
- 4) FASTENED 4" O.C. AND STAGGERED BETWEEN 1" AND 1-1/2" FROM TOP BACKSIDE EDGE OF FASCIA COVER. THE MAXIMUM RATING ACHIEVED FOR (L) DIMENSION FASCIA HEIGHT IS AS FOLLOWS:
  390 PSF ◎ 6", AND 730 PSF ◎ 4"

## ONEDEK SARNACLAD METAL EDGE HIGH WIND

