

NOTES:

- 1) NAILERS SHALL BE SECURELY ANCHORED TO THE DECK TO RESIST A FORCE OF 300 POUNDS PER LINEAL FOOT IN ANY DIRECTION.
- 2) VAPOR RETARDER TIE-IN ALONG VERTICAL TRANSITION TO BE INSTALLED PER DESIGNER RECOMMENDATION.
- 3) VAPOR RETARDER SHALL BE SEALED AT EDGES.

WALL TRANSITION

