

## NOTES:

- 1) NEW OR EXISTING WOOD NAILERS SHALL BE ATTACHED ACCORDING TO THE D.O.R., LOCAL CODE, OR INSURANCE REQUIREMENTS, WHICHEVER IS MORE STRINGENT. NAILER HEIGHT TO MATCH TOP SURFACE TO WHICH MEMBRANE IS TO BE APPLIED.
- 2) REMOVE ALL GRAVEL AT TIE-IN AREA.
- 3) CONSULT SIKA SARNAFIL FOR RECOMMENDATIONS FOR TIE-IN TO COAL-TAR PITCH.

## TEMPORARY TIE-IN TO EXISTING B.U.R.

