

NOTES:

- 1) NEW OR EXISTING WOOD NAILERS SHALL BE ATTACHED ACCORDING TO THE D.O.R., LOCAL CODE, OR INSURANCE REQUIREMENTS, WHICHEVER IS MORE STRINGENT. NAILER HEIGHT TO MATCH TOP SURFACE TO WHICH MEMBRANE IS TO BE APPLIED.
- 2) BRING BAREBACK MEMBRANE OVER ROOF EDGE AND DOWN OUTSIDE FACE OF WALL, COVERING WOOD NAILER(S) COMPLETELY. BRING FELTBACK MEMBRANE TO ROOF EDGE ONLY.
- 3) FASTENER WITHDRAWAL RESISTANCE SHOULD BE 100 LB MIN. USE EITHER GALVANIZED ANNULAR RING NAILS PENETRATING 1-1/4" MIN. OR NO. 8 MIN. SCREWS PENETRATING 3/4". FASTENER IS PLACED EITHER CENTERED INTO TOP WOOD NAILER OR 1" FROM TOP EDGE OF CLEAT HOOK STRIP ⊚ 4" O.C.
- 4) FASTENED 4" O.C. AND STAGGERED BETWEEN 1" AND 1-1/2" FROM TOP BACKSIDE EDGE OF FASCIA COVER. THE MAXIMUM RATING ACHIEVED FOR (L) DIMENSION FASCIA HEIGHT IS AS FOLLOWS:
 210 PSF ❷ 8", 310 PSF ❷ 6", AND 470 PSF ❷ 4" (IF CALCULATED PROJECT VALUES EXCEED LISTED RESULTS, DETAIL 1-1A MUST BE USED)

SARNACLAD METAL EDGE (FELTBACK MEMBRANE)

