

<u>NOTES</u>

- 1) FOLLOW EXISTING SINGLE-PLY MANUFACTURER RECOMMENDATIONS FOR TIE-IN DETAIL AND RECOMMENDATION FOR CLEANING MEMBRANE.
- 2) CLEAN EXISTING ROOF MEMBRANE PRIOR TO HOT-AIR WELDING,
- 3) CONSULT SIKA SARNAFIL FOR RECOMMENDATIONS FOR TIE-IN TO COAL-TAR PITCH.

TIE-IN TO EXISTING ROOF

