



HOW-TO GUIDE



SikaQuick® Asphalt Patch

MIX-IN-THE-BAG • RAPID CURING • BLACKTOP REPAIR PATCH

MATERIALS:

Required: SikaQuick® Asphalt Patch • Safety glasses and gloves • Trowel or tooling spatula

Optional: Scissors/utility knife • Brush (clean/remove debris)

SITE PREP & PROCEDURE

1. The substrate should be clean, dry, and free of any contaminants. Ensure no curing compounds or other contaminants are remaining on the substrate before the application.
2. Wear safety glasses and gloves. **Tip:** before mixing it is recommended to lightly shake the powder from each of the corners to loosen material and ensure no powder gets trapped in the corners of the packaging. This will prevent the material from clumping.
3. To begin **roll** the pouch (in the direction of arrows) toward the central burst seal until it ruptures and allows materials to combine. **Mix** thoroughly for approximately **40-60** seconds by forcing the material to travel in the bag from one end to the other. Periodically knead to ensure a cohesive and fluid mixture.
4. After mixing **tear/cut** one of the bag's corners and **pour** mixed material into the hole/spall. The material will settle into the pothole or spall. Material will self-level into the void and cure to a smooth finish.
5. For a textured finish: after pouring the product into the void, wait approximately 3 - 5 minutes before lightly working the surface of the product with a trowel or tooling spatula to create the desired texture.
6. Patch material will appear brown when first applied and become black as it cures.

