

- 3) AIR BARRIER SHALL BE SEALED AT EDGES.
- 4) SARNAVAP IS INSTALLED AND TURNED DOWN THE WALL 3" AND THEN SEALED WITH SIKA MULTISEAL 515 SELF ADHERED SEAM TAPE.

