

NOTES:

- 1) VAPOR RETARDER SHALL BE SEALED AT EDGES
- 2) MAKE SURE TO LEAVE ENOUGH ROOM BETWEEN THE RIB AND SARNACLAD RIDGE CAP

PEAK/RIDGE VENT DETAIL - DECOR

