

NOTES:

- 1) NAILERS SHALL BE SECURELY ANCHORED TO THE DECK TO RESIST A FORCE OF 300 POUNDS PER LINEAL FOOT IN ANY DIRECTION.
- 2) FOLLOW EXISTING SINGLE-PLY MFG. RECOMMENTIONS FOR TIE-IN DETAIL AND RECOMMENDATION FOR CLEANING MEMBRANE.
- 3) CLEAN EXISTING SINGLE-PLY MEMBRANE PRIOR TO HOT-AIR WELDEING.
- 4) VAPOR RETARDER SHALL BE SEALED AT EDGES

TEMPORARY TIE-IN TO EXISTING B.U.R.

