

BATCHING INSTRUCTIONS

1

Add fibers LAST

* ADD ONLY AFTER ALL OTHER
MATERIALS & TRUCK IS
WASHED DOWN.

NO EXCEPTIONS!*

*Note: Bring **SLUMP UP** before adding fibers.*

LAST



2

ONE (1) BAG Per Drum Turn

(or until bag disappears)



x 1

3

MIX FOR 5 minutes at high speed (~15 RPMs)



5 MIN



HIGH SPEED