

NOTES:

- 1) SEALANT IS A MAINTENANCE ITEM AND IS NOT COVERED UNDER THE WARRANTY.
- 2) REMOVE ANY EXISTING ROOFING AND METAL EDGE MATERIALS DOWN TO EXISTING WOOD BLOCKING. ADD ADDITIONAL WOOD NAILER AS REQUIRED TO MATCH HEIGHT OF EXISTING ROOF ASSEMBLY.
- 3) SARNACLAD SURFACE SHALL BE PROPERLY PREPPED.
- 4) KEEP SIKALASTIC EP PRIMER EVEN WITH SIKALASTIC LAM FLASHING.

LAM THRU-WALL SCUPPER

