

NOTES:

- 1) INSTALL TERMINATION BAR WITH A 1/4" GAP BETWEEN ADJOINING SECTORS
- 2) TERMINATION BAR MUST BE CUT AT INSIDE AND OUTSIDE CORNERS. DO NOT BEND AROUND CORNERS.
- 3) TERMINATION BAR MUST BE FASTENED WITHIN 1" MAX OF EACH BAR END
- 4) SEALANT IS A MAINTENANCE ITEM AND IS NOT COVERED UNDER SIKAPLAN WARRANTIES
- 5) THIS DETAIL ONLY QUALIFIES FOR SIKAPLAN SYSTEM WARRANTIES

SIKAPLAN WALL/EDGE TERMINATION

