


APPLY SIKAFLEX - 1A
AROUND DOWEL. CUT A
HOLE IN THE CENTER OF
FLASHING PIECE SMALLER
THAN DOWEL DIAMETER,
STRETCH FLASHING PIECE
DOWN DOWEL AND HOT—AIR
WELD IN—PLACE.



NOTES:

- 1) ALL FLASHING SHALL EXTEND A MIN. OF 8 INCHES ABOVE THE OVERBURDEN.
- 2) METAL COUNTERFLASHING AND COPING STONE ARE TO BE INSTALLED TO MEET LOCAL CODES AND REQUIREMENTS.
- 3) SEALANT IS A MAINTENANCE ITEM NOT COVERED UNDER SIKA SARNAFIL WARRANTY.

COPING STONE

