


NOTES:

- 1) INSTALL TERMINATION BAR WITH A 1/4" GAP BETWEEN ADJOINING SECTIONS.
- 2) TERMINATION BAR MUST BE CUT AT INSIDE AND OUTSIDE CORNERS. DO NOT BEND AROUND CORNERS.
- 3) TERMINATION BAR MUST BE FASTENED WITHIN 1" MAX. OF EACH BAR END.
- 4) FOR USE ON SMOOTH / SOLID CONCRETE OR MASONRY WALLS, NOT TO BE USED ON WOOD.
- 5) THIS DETAIL ONLY QUALIFIES FOR SIKAPLAN SYSTEM WARRANTIES.
- 6) SEALANT IS A MAINTENANCE ITEM AND IS NOT COVERED UNDER THE SIKAPLAN WARRANTY.

SIKAPLAN PARAPET WALL TERMINATION



AS A MEMBRANE MANUFACTIONER, SIKA CORPORATION (STACK) REVEWS DETAILS BY THE CONSULTANT, ARCHITECT AND/OR ENGINEER FOR A PROJECT SOLELY FOR THE PURPOSE OF DETERMINING A STACK WARRANT WAY ISSUE FOR THE PROJECT. THIS REVIEW IS NOT TO BE CONSTRUED AS A PPROVAL OF DETAILS BY SIKA AND IS NOT BEING CONDUCTED IN LEU OF SOUND ENGINEERING AND ARCHITECTURAL PRACTICES AND JUDGMENT AND SHOULD NOT BE RELIED UPON FOR THAT PURPOSE. SIKA CORPORATION ASSUMES NO LUBBILITY WITH RESPECT TO THE DESIGN OF THE ROOFING OR WATERPROOFING SYSTEM. THE ARCHITECT, CONSULTANT AND/OR ENGINEER OR DESIGN PROFESSIONAL FOR A PARTICULAR PROJECT BEARS THE SOLE RESPONSIBILITY FOR THE DESIGN OF THE ROOFING OR WATERPROOFING SYSTEM. FOR THE THIS SAID SHOW, AND FOR DETERMINING THEIR SULTIBALITY OR A PARTICULAR PROJECT OR APPLICATION. WHILE SIKA PROVIDES GENERAL INSTRUCTIONS FOR THE INSTRUCTION OF THE MOSPHAME AS WELL AS TRAINING FOR SIKA AUTHORIZED APPLICATORS, THE MEANS AND METHODS USED BY THE CONTRACTOR FOR SURFACE PREPARATION AS WELL AS THE MEANS AND METHODS EMPLOYED BY THE CONTRACTOR IN THE INSTRUCTION OF THE SIKA MEMBRANE AS WELL AS TRAINING FOR SIKA AUTHORIZED APPLICATORS, THE MEANS AND METHODS USED BY THE CONTRACTOR IN THE INSTRUCTION OF THE SIKA MEMBRANE ARE THE RESPONSIBILITY OF THE CONTRACTOR. ALL SALE OF SIKA PRODUCTS AND SERVICES ARE SUBJECT TO SIKA'S TERMS AND CONDITIONS OF SALE AVAILABLE AT USA, SARNAFIL. SIKA.COM.