Application Instructions



Rapid Hardening Repair Mortar with Extended Working Time.

Sika Quick is a 1-component, rapid hardening, early strength gaining cementitous based material for patching concrete.



- ▲ Where to use:
- Use on grade, above and below grade on concrete.
- Highway overlays and repairs.
- Structural Repair material for concrete roadways, parking structures, bridges, dams and ramps.
- Full depth patching.
- Economical patching material for horizontal repairs of concrete and mortars.



Coverage:

▲ SikaQuick 1000 Mortar Approximately 0.43 cu.ft

▲ SikaQuick 1000 Concrete

When extended with 25 lbs. of 3/8 in gravel approximate yield = 0.6 cu.ft



▲ Packaging:

50 lb – Multi wall Bag 40 Bags/Pallet





Cementitious Substrates:

- Should be clean and sound.
- Remove contaminations and bond inhibiting materials from repaired area.
- Obtain exposed/fractured aggregate surface ~1/8 to 1/4 inch profile (ICRI CSP 6 & above).
- Substrate must be saturated surface dry (SSD) with no standing water.




▲ Cementitious Substrates:

 Surface should be cleaned and roughened to create a profile.






- ▲ Saw cut around perimeter or repair area to achieve a minimum 1/8" shoulder.
- ▲ This will eliminate feather edging the product and give a clean transition for the repair.





Steel:


- Remove all corrosion and contaminants from exposed steel.
- Surface should be cleaned thoroughly by blast cleaning or mechanical means.
- Exposed steel should be cleaned to white steel.
- If half of the diameter is exposed, chip behind bar, ½" minimum for mortar only.





Steel Preparation

Steel should be cleaned to a bright metal finish.





Sika Corporation

Tools Required

- ▲ ½" Drill Motor
- ▲ Low speed drill 400-600 rpm
- Mortar mixer or Jiffy mixer
- Margin trowel
- Steel/Mag Trowel
- Spatula





▲ Saw cut around perimeter or repair area to achieve a minimum 3/8" shoulder. This will eliminate feather edging the product and give a clean transition for the repair.



Steel:

- Remove all corrosion and contaminants from exposed steel.
- Surface should be cleaned thoroughly by blast cleaning or mechanical means.
- Exposed steel should be cleaned to white steel.
- If half of the diameter is exposed, chip behind bar, ½" minimum for mortar only.



Mixing

Mixing Equipments

- . Mortar Mixer
- Drill and Paddle.

Wet down tools and equipments before proceeding to mix.





Mixing- SikaQuick Mortar

- Water 4.5-5 Pts/Bag
- Latex-R- 4.5-5 Pts/Bag.
- Start with adding liquid to the mixing container.
- 4. Slowly add powder.
- Once all the powder is added mix for <u>3 minutes</u>.
- Do not add any more than5 pts of liquid. water.





Mixing- SikaQuick Concrete

- . Water 4.5-5 Pts/Bag
- Latex-R- 4.5-5 Pts/Bag.
- Stone 3/8 gravel 25#/bag.
- 4. Stone Weigh Before SSD.
- 5. Start with adding liquid to the mixing container.
- 6. Slowly add powder.
- Once all the powder is added and mixed add stone.
- Mix time <u>3 minutes</u> after everything is added.
- Do not add any more than5 pts of liquid. water.





Aggregate Selection & SSD



Consult Technical Data Sheets for detailed recommendations on aggregate selection.



Min / Max application thickness

Neat

Min 1/4 inch

Max1 inch

Extended

Min1 inch

Max 6 inches



Scrub/Slurry Coat





Placement





Placement





Finishing





SikaTop Curing

- Cure as per ACI recommendations.
 - Curing is required.
- Moist cure with wet burlap and polyethylene, a fine mist of water.
- Moist curing should commence immediately after finishing.
- Protect newly applied material from direct sun light, wind, rain and frost.





Curing





Sika Technical Data Sheets can be obtained via:

www.sikaconstruction.com

Refer to data sheets for specific information on each Sika product.

