



**NOTES:**

- 1) INSTALL TERMINATION BAR WITH A 1/4" GAP BETWEEN ADJOINING SECTIONS.
- 2) TERMINATION BAR MUST BE CUT AT INSIDE AND OUTSIDE CORNERS. DO NOT BEND AROUND CORNERS.
- 3) TERMINATION BAR MUST BE FASTENED WITHIN 1" MAX. OF EACH BAR END.
- 4) WALLS EXCEEDING 45" IN HEIGHT WILL REQUIRE ADDITIONAL FASTENING. REFER TO TECHNICAL BULLETIN 24-01
- 5) THIS DETAIL QUALIFIES FOR 46 MPH SIKAPLAN SYSTEM WARRANTY ONLY.



## SIKAPLAN HIGHWALL FLASHING

DETAIL NUMBER:

**SPU-5**

ISSUE / REVISION DATE:

**12/2025**

ACCEPTABLE SYSTEMS: SIKAPLAN UNIVERSAL

781-828-5400

[usa.sika.com/sikaplan](http://usa.sika.com/sikaplan)

NOT TO SCALE

AS A MEMBRANE MANUFACTURER, SIKA CORPORATION ("SIKA") REVIEWS DETAILS PREPARED BY THE CONSULTANT, ARCHITECT AND/OR ENGINEER FOR A PROJECT SOLELY FOR THE PURPOSE OF DETERMINING IF A SIKA WARRANTY MAY ISSUE FOR THE PROJECT. THIS REVIEW IS NOT TO BE CONSTRUED AS APPROVAL OF DETAILS BY SIKA AND IS NOT BEING CONDUCTED IN LIEU OF SOUND ENGINEERING AND ARCHITECTURAL PRACTICES AND JUDGMENT AND SHOULD NOT BE RELIED UPON FOR THAT PURPOSE. SIKA CORPORATION ASSUMES NO LIABILITY WITH RESPECT TO THE DESIGN OF THE ROOFING OR WATERPROOFING SYSTEM, THE ARCHITECT, CONSULTANT AND/OR ENGINEER OR DESIGN PROFESSIONAL FOR A PARTICULAR PROJECT BEARS THE SOLE RESPONSIBILITY FOR THE DESIGN OF THE ROOFING OR WATERPROOFING SYSTEM, FOR THE PREPARATION AND APPROVAL OF THE DETAILS AND SHOP DRAWINGS, AND FOR DETERMINING THEIR SUITABILITY FOR A PARTICULAR PROJECT OR APPLICATION. WHILE SIKA PROVIDES GENERAL INSTRUCTIONS FOR THE INSTALLATION OF ITS MEMBRANE AS WELL AS TRAINING FOR SIKA AUTHORIZED APPLICATORS, THE MEANS AND METHODS USED BY THE CONTRACTOR FOR SURFACE PREPARATION AS WELL AS THE MEANS AND METHODS EMPLOYED BY THE CONTRACTOR IN THE INSTALLATION OF THE SIKA MEMBRANE ARE THE RESPONSIBILITY OF THE CONTRACTOR. ALL SALE OF SIKA PRODUCTS AND SERVICES ARE SUBJECT TO SIKA'S TERMS AND CONDITIONS OF SALE AVAILABLE AT [USA.SIKA.COM/SARNAFIL](http://USA.SIKA.COM/SARNAFIL).